


RSW-0310 S2910-H





# HPOE

RG-S2910- 24GT4SFP-UP- H	24 10/100/1000M PoE/PoE+ <b>4 HPOE</b> 4 1000M SFP	POE HPOE POE 1.XX 2.XX 90W 3.XX 60W
RG-PBOX-DC12	RJ45 POE <b>DC12V</b>	

HPOE

HPOE  
RG-PBOX-AC24

RG-S2910-24GT4SFP-UP-H  
RG-PBOX-DC12  
POE

POE

# Contents




1




1







19



I




(  
4





# PBOX






**PBOX**

PBOX  
PBOX

M4\*20mm





RG-PBOX

Data Out

PD

HPOE

1-4

Data&Power in

1m

18AWG

RG-

PBOX-DC12

CCD

C/CS

I



I



OT

OT




PE

PE

1	
2	
3	OT
4	


I



I



20



**RG-PBOX**

Data out

Data&Power in

HPOE

RG-PBOX-DC12

PBOX



# Contents





1 Console

2 Telnet/SSH

CLI

3 SNMP

CLI

4 WEB

WEB

admin/admin

Rupee



www.rupia.com

# | Console




PC

1

2



# | Console



# | Console



**CLI**



Ruijie>enable



# | Console



?

11.X CLI

10.X

CLI

Ruijie#show version /show version slots / show cpu /show memory /show interface status /show ip route /show arp /show fan / show power /show temperature....

Ruijie#show run //  
Ruijie(config-if-GigabitEthernet 1/1)#show this //

Ruijie#wr //

Ruijie#ping 8.8.8.8 // Ping



# Telnet



## Telnet






# Contents





1	FTP		
2	TFTP		FTP
3	USB	USB	5

# FTP



1		FTP Server		USB0	S6010	FLASH
		<pre> Ruijie(config)#ftp-server username admin Ruijie(config)#ftp-server password ruijie Ruijie(config)#ftp-server topdir tmp:/ Ruijie(config)#ftp-server timeout 300 Ruijie(config)#ftp-server enable           </pre>				
2	PC	FTP Client	FLASHFTP		FTP	PC
	S6010					
3	PC	FTP		FTP Server		
4	Upgrade			USB		

FTP


USB

USB  
Upgrade

FTP

FTP  
U

# TFTP



1	PC	TFTP Server		PC	S6010
2	S2910	TFTP Client	TFTP	,	flash
	tmp		tmp		
	Ruijie#copy tftp://192.168.1.1/S2910_RGOS11.4(1)B3_02211500_install.bin				
	flash:/S2910_RGOS11.4(1)B3_02211500_install.bin				
3	Upgrade		upgrade		

TFTP

USB

TFTP

TFTP

USB  
Upgrade

U

TFTP



FTP

FTP

TCP

TFTP

UDP

TFTP

[www.ruijie.com.cn](http://www.ruijie.com.cn)

[www.ruijie.com.cn/service.aspx](http://www.ruijie.com.cn/service.aspx)

[support.ruijie.com.cn](http://support.ruijie.com.cn)

[webchat.ruijie.com.cn](http://webchat.ruijie.com.cn)

4008-111-000