


RG-AP820-A(X)



RG-AP820-A(X)

POE DC

www.ruijie.com.cn



802.3af PoE

Ruijie

```

conf
Ap-mode fat///
  VLAN 1
enable
configure terminal
vlan 1
exit

```

```

      Wlan1          wlan2
dot11 wlan 1
vlan 1----->   Vlan 1
broadcast-ssid
ssid AP1  ----->SSID      AP1
Exit

```

```

                                LAN
interface GigabitEthernet 0/1
no encapsulation
encapsulation dot1Q 1
exit

```

```

      radio1      vlan1
interface Dot11radio 1/0
no encapsulation
encapsulation dot1Q 1
exit

```

```

      radio1      wlan1
interface dot11radio 1/0
wlan-id 1
channel 6
chan-wide 20
Exit


```

```

----->          radio          wlan id


                                Vlan 1      IP
no in bvi 1
int bvi 1
ip add 192.168.0.1 255.0.0.0

```



11ax 11ax STA

STA 11ax



0.8us

1.6us 3.2us

AP MU MIMO 802.11AC 802.11AX STA

11AX OFDMA

11ax 2019 11ax

www.ruijie.com.cn

www.ruijie.com.cn/service.aspx

support.ruijie.com.cn

webchat.ruijie.com.cn

4008-111-000